








# Webcam Mount Parts




# Webcam Mount Instructions

1	<p>Attach the webcam to the base using the metal screw.</p>	 An illustration showing a hand holding a metal screw and inserting it into a hole on the back of a webcam. An arrow points to the screw's tip.
2	<p>Insert the hanger into the base with the hook facing backward and the "collar" of the base pointing up.</p>	 An illustration showing a hand inserting a metal hanger into the base of the webcam. The hanger has a hook and a collar. An arrow points to the collar.
3	<p>Screw the small plastic screw into one of the holes to set the height of your webcam.</p>	 An illustration showing a hand using a screwdriver to screw a small plastic screw into one of the holes on the side of the webcam base. An arrow points to the screw.
4	<p>Hang the webcam hanger on your monitor, draping the webcam's cord <b>over the top</b> of the monitor.</p>	 An illustration showing a hand hanging the webcam hanger on the top edge of a monitor. The webcam's cord is draped over the top of the monitor.

# Troubleshooting

Webcams and monitors come in all shapes and sizes. Review this checklist to troubleshoot any problems with your set up:

- Carefully compare your mount to the diagram below
- Make sure that the tripod screw is tight and your webcam cannot move on the base
- Check that the webcam cord is draped over the top of your monitor
- Confirm that the back of the hanger and base are resting on your monitor screen
- Verify that the top of your monitor is less than 1½" (38 mm) thick
- Add the plastic and rubber clips, and 3M tape if needed
- Contact us if you need help!



Customer Satisfaction is our **#1 priority**.

We want to hear from you, if you have ANY questions or feedback on your purchase.

✉ [info@luckyducktech.com](mailto:info@luckyducktech.com)

